

WINCH FAIRLEAD HOLE COVER

INSTALLATION INSTRUCTIONS



SAFETY

Know Safety, no injury. Know injury, no safety. ~Author Unknown

If there are any questions, call 1-855-HHTOUGH

- **READ ALL SAFETY INSTRUCTIONS BEFORE INSTALLATION**
 - FOLLOW ALL INSTRUCTIONS FOR PROPER ASSEMBLY
 - WEAR APPROPRIATE EYE PROTECTION
 - EXERCISE CARE WHEN LIFTING COMPONENTS
 - USE APPROPRIATE TORQUE FOR BOLTS
 - BLUE THREAD LOCKING COMPOUND IS RECOMMENDED ON ALL BOLTS






600-56-0945

Suggested Torque Values For Steel Grade 5 Standard Bolts		
BOLT DIAMETER (INCH)	THREADS PER INCH	TORQUE (POUND - FEET)
1/4	20	7
5/16	18	14
3/8	16	25
7/16	14	40
1/2	13	60
9/16	12	88
5/8	11	120
3/4	10	200
7/8	9	302
1	8	466

Suggested Torque Values For Steel Grade 8.8 Metric Bolts		
BOLT DIAMETER (mm)	THREAD PITCH (mm)	TORQUE (POUND- FEET)
6	1.0	7
8	1.25	16
10	1.5	32
12	1.75	55
14	2.0	88
16	2.0	140
18	2.5	195
20	2.5	275
22	2.5	375
24	3.0	475

I. PARTS LIST





600-56-0945

ITEM NO.	Default/ QTY.	PART NUMBER	DESCRIPTION
1	1	601-56-5295	FAIRLEAD CUTOUT COVER
2	1	60H-56-0085	INSTALL KIT #85

REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT.

If there are any questions, call 1-855 HHTOUGH or email HHORDERS@hammerheadarmor.com

II. TOOL LIST

1. Basic Tool Kit
2. 9/16" socket and
3. T45 Torx

III. INSTALLATION

1. Park vehicle on level surface.
2. Engage parking brake.
3. Place the torx head bolt threw the cover and bumper with the torx head on the outside on the bumper. Use a flat washer on the inside on the bumper and the provide nylock nut. Repeat for both sides before tightening.
4. Tighten to suggested torque value.

Congratulations! Your Installation is now complete.

Thank You for your purchase!